

Flexible Edging Installation Guide



STEP 1

Using a spade or shovel, clear the area where edging is to be placed of turf and debris. Place the edging in the desired shape and location on cleared surface with the anchoring tabs facing toward the planting bed.



STEP 2

Hammer the included anchoring spikes through the tabs to hold the edging in place. The maximum spacing of the spikes is every 4' / 1.2m. If you desire additional anchoring, spike packs are available separately.



STEP 3

Backfill to the top of the edging with mulch or other ground cover.



USING THE CONNECTOR

When joining two pieces of edging, use the included overlapping connector. It is designed to overlay on the top of the end tab of each piece, so that when spiked, it minimises the gap between two pieces of edging.

HELPFUL TIPS

- **PROTECTIVE EYEWEAR:** During installation it is recommended to wear protective eyewear.
- **WEAR GLOVES:** Gardening or work gloves are recommended when handling.
- **CUTTING:** When cutting edging for best results it is recommended to cut at the midpoint between the anchoring tabs using hand snips or a fine tooth saw.

WATCH INSTALLATION VIDEO



<https://buyfactory.direct/instructions/garden-edge-black-flexible>